

# RNA-seq and Genomics File Formats

### Levels of organization






### RNA-seq

- Isolate a tissue or single cell
- Extract total RNA
- Use the poly-A tail to enrich for mRNA
- Convert the mRNA to cDNA
- Sequence the cDNA on a next-generation sequencer (Illumina)
- The reads from the sequencer are returned as fastq files.

### **Quality Control**

- Use FASTQC to check fastq files for quality
- Use Trimmomatic to trim
  - Remove adapter sequences
  - Remove low quality reads or parts of reads
- Recheck with FASTQC
- Interpreting FASTQC results: <a href="https://hbctraining.github.io/Intro-to-rnaseq-hpc-salmon/lessons/qc">https://hbctraining.github.io/Intro-to-rnaseq-hpc-salmon/lessons/qc</a> fastqc assessment.html

### Read Mapping (many options)



### Normalizing Read Counts

- Longer genes will have more reads because they occupy more of the genome
- Samples with more reads will have higher read counts
- Normalization
  - RPKM: The number of reads normalized by the total read number and length of each transcript
  - FPKM: Takes into account that reads can be paired but otherwise the same is RPKM
  - TPM: Like RPKM/FPKM, but normalized to ensure that the average value is constant across samples (TPM is probably the best to use because it ensures the normalized values sum to the same total value across samples)

# Statistical Analysis

### Each column is a sample

# Each row is a gene

GENE ID	KD.2	KD.3	OE.1	OE.2	OE.3	IR.1	IR.2	IR.3
1/2-SBSRNA4	57	41	64	55	38	45	31	39
A1BG	71	40	100	81	41	77	58	40
A1BG-AS1	256	177	220	189	107	213	172	126
A1CF	0	1	1	0	0	0	0	0
A2LD1	146	81	138	125	52	91	80	50
A2M	10	9	2	5	2	9	8	4
A2ML1	3	2	6	5	2	2	1	0
A2MP1	0	0	2	1	3	0	2	1
A4GALT	56	37	107	118	65	49	52	37
A4GNT	0	0	0	0	1	0	0	0
AA06	0	0	0	0	0	0	0	0
AAA1	0	0	1	0	0	0	0	0
AAAS	2288	1363	1753	1727	835	1672	1389	1121
AACS	1586	923	951	967	484	938	771	635
AACSP1	1	1	3	0	1	1	1	3
AADAC	0	0	0	0	0	0	0	0
AADACL2	0	0	0	0	0	0	0	0
AADACL3	0	0	0	0	0	0	0	0
AADACL4	0	0	1	1	0	0	0	0
AADAT	856	539	593	576	359	567	521	416
AAGAB	4648	2550	2648	2356	1481	3265	2790	2118
AAK1	2310	1384	1869	1602	980	1675	1614	1108
AAMP	5198	3081	3179	3137	1721	4061	3304	2623
AANAT	7	7	12	12	4	6	2	7
AARS	5570	3323	4782	4580	2473	3953	3339	2666
**000	4454	2727	2201	2121	1240	2400	2074	1/27

## Types of Files Involved

- Fastq
  - Reads
- Fasta
  - Genome
- GFF, GTF
  - Genome Annotation
- SAM, BAM
  - Aligned Reads
- Output files
  - Tables of RPKM, FPKM, or TPM

```
--->gzip -cd L2I S1 L001 R1 001.fastq.gz | head
@M00805:5:000000000-A0VLL:1:1101:16473:1320 1:N:0:1
NTTGTCATCAGCTGAAGATGAAATAGGATGTAATCAGACGACACAGGAAGCAGATTTTGCTAAT
TTGGAACTAGGTCAGCTGAAGATCCTGTGAGCGAAGTTCCGGCAGTGTCACAGCAC
+
AFHFHHHHHHHFGHDDHFBFHDFFHFFFHHHFFA=@BEEEED)@<B?BE3==?EEEE
@M00805:5:000000000-A0VLL:1:1101:15023:1321 1:N:0:1
NAGAAATCACAGACATACAAAGCAGTCTGTGTCCTTAGGTCCTGAGCAGCCTCCAGCACATTCT
AGCATCTGCCGTCACATTGTTCTGCACACACCGTCCTTGTCACTGCAGAAGACAGA
+
@M00805:5:000000000-A0VLL:1:1101:14046:1321 1:N:0:1
NTTTCGTGGAAGTGGGTTACCTGACAGTGTGCACGCCCCCAGCAGGTTCACAATATTCTCGTGG
```

### FASTQ quality scores

• Modern sequencers use Phred+33 for their quality scores

 What do quality scores mean? — HTS2018 1.0 documentation (duke.edu) >NG 008679.1:5001-38170 Homo sapiens paired box 6 (PAX6) ACCCTCTTTTCTTATCATTGACATTTAAACTCTGGGGCAGGTCCTCGCGTAGAACGCGGCTGTCAGATCT GCCACTTCCCCTGCCGAGCGGCGGTGAGAAGTGTGGGAACCGGCGCTGCCAGGCTCACCTGCCTCCCCGC CCTCCGCTCCCAGGTAACCGCCCGGGCTCCGGCCCCGGCCCGGCTCGGGGCCCGCGGGCCTCTCCGCTG CCAGCGACTGCTGTCCCCAAATCAAAGCCCGCCCCAAGTGGCCCCGGGGGCTTGATTTTTGCTTTTAAAAG GAGGCATACAAAGATGGAAGCGAGTTACTGAGGGAGGGATAGGAAGGGGGGGTGGAGGAGGGACTTGTCTT TGCCGAGTGTGCTCTTCTGCAAAAGTAGCAAAATGTTCCACTCCTAAGAGTGGACTTCCAGTCCGGCCCT GAGCTGGGAGTAGGGGGGGGGGAGTCTGCTGCTGCTGTCTGCTAAAGCCACTCGCGACCGCGAAAAATGCA GGAGGTGGGGACGCACTTTGCATCCAGACCTCCTCTGCATCGCAGTTCACGACATCCACGCTTGGGAAAG TCCGTACCCGCGCCTGGAGCGCTTAAAGACACCCTGCCGCGGGTCGGGCGAGGTGCAGCAGAAGTTTCCC GCGGTTGCAAAGTGCAGATGGCTGGACCGCAACAAAGTCTAGAGATGGGGTTCGTTTCTCAGAAAGACGC >sp|P11274|BCR\_HUMAN Breakpoint cluster region protein OS=Homo sapiens OX=9606 GN=BCR PE=1 SV=2

MVDPVGFAEAWKAQFPDSEPPRMELRSVGDIEQELERCKASIRRLEQEVNQERFRMIYLQ TLLAKEKKSYDRORWGFRRAAOAPDGASEPRASASRPOPAPADGADPPPAEEPEARPDGE GSPGKARPGTARRPGAAASGERDDRGPPASVAALRSNFERIRKGHGOPGADAEKPFYVNV EFHHERGLVKVNDKEVSDRISSLGSOAMOMERKKSOHGAGSSVGDASRPPYRGRSSESSC GVDGDYEDAELNPRFLKDNLIDANGGSRPPWPPLEYOPYOSIYVGGMMEGEGKGPLLRSO STSEOEKRLTWPRRSYSPRSFEDCGGGYTPDCSSNENLTSSEEDFSSGOSSRVSPSPTTY RMFRDKSRSPSONSOOSFDSSSPPTPOCHKRHRHCPVVVSEATIVGVRKTGOIWPNDGEG AFHGDADGSFGTPPGYGCAADRAEEORRHODGLPYIDDSPSSSPHLSSKGRGSRDALVSG ALESTKASELDLEKGLEMRKWVLSGILASEETYLSHLEALLLPMKPLKAAATTSOPVLTS OOIETIFFKVPELYEIHKEFYDGLFPRVOOWSHOORVGDLFOKLASOLGVYRAFVDNYGV AMEMAEKCCOANAOFAEISENLRARSNKDAKDPTTKNSLETLLYKPVDRVTRSTLVLHDL LKHTPASHPDHPLLODALRISONFLSSINEEITPRROSMTVKKGEHROLLKDSFMVELVE GARKLRHVFLFTDLLLCTKLKKOSGGKTOOYDCKWYIPLTDLSFOMVDELEAVPNIPLVP DEELDALKIKISOIKNDIOREKRANKGSKATERLKKKLSEOESLLLLMSPSMAFRVHSRN GKSYTFLISSDYERAEWRENIREOOKKCFRSFSLTSVELOMLTNSCVKLOTVHSIPLTIN KEDDESPGLYGFLNVIVHSATGFKOSSNLYCTLEVDSFGYFVNKAKTRVYRDTAEPNWNE EFEIELEGSOTLRILCYEKCYNKTKIPKEDGESTDRLMGKGOVOLDPOALODRDWORTVI AMNGIEVKLSVKFNSREFSLKRMPSRKOTGVFGVKIAVVTKRERSKVPYIVROCVEEIER RGMEEVGIYRVSGVATDIOALKAAFDVNNKDVSVMMSEMDVNAIAGTLKLYFRELPEPLF TDEFYPNFAEGIALSDPVAKESCMLNLLISLPEANLLTFLFLLDHLKRVAEKEAVNKMSL HNLATVFGPTLLRPSEKESKLPANPSOPITMTDSWSLEVMSOVOVLLYFLOLEAIPAPDS KROSILFSTEV

```
##gff-version 3.2.1
##sequence-region ctg123 1 1497228
ctg123 . gene
                         1000
                               9000
                                               ID=gene00001; Name=EDEN
ctg123 . TF binding site 1000
                                               ID=tfbs00001;Parent=gene00001
                               1012
ctg123 . mRNA
                         1050
                                9000
                                               ID=mRNA00001; Parent=gene00001; Name=EDEN.1
ctg123 . mRNA
                         1050
                                9000
                                               ID=mRNA00002; Parent=gene00001; Name=EDEN. 2
ctg123 . mRNA
                         1300
                                               ID=mRNA00003; Parent=gene00001; Name=EDEN.3
                                9000
ctg123 . exon
                         1300
                               1500
                                               ID=exon00001;Parent=mRNA00003
                         1050
                                               ID=exon00002;Parent=mRNA00001,mRNA00002
ctg123 . exon
                                1500
ctg123 . exon
                          3000
                                3902
                                               ID=exon00003; Parent=mRNA00001, mRNA00003
ctg123 . exon
                          5000
                                5500
                                               ID=exon00004; Parent=mRNA00001, mRNA00002, mRNA00003
ctg123 . exon
                         7000
                                9000
                                               ID=exon00005; Parent=mRNA00001, mRNA00002, mRNA00003
ctg123 . CDS
                         1201
                               1500
                                               ID=cds00001;Parent=mRNA00001;Name=edenprotein.1
ctg123 . CDS
                          3000
                                               ID=cds00001; Parent=mRNA00001; Name=edenprotein.1
                                3902
ctg123 . CDS
                                               ID=cds00001;Parent=mRNA00001;Name=edenprotein.1
                          5000
                                5500
ctg123 . CDS
                                               ID=cds00001; Parent=mRNA00001; Name=edenprotein.1
                          7000
                                               ID=cds00002;Parent=mRNA00002;Name=edenprotein.2
ctg123 . CDS
                         1201
                                1500
ctg123 . CDS
                          5000
                                               ID=cds00002; Parent=mRNA00002; Name=edenprotein.2
                                               ID=cds00002;Parent=mRNA00002;Name=edenprotein.2
ctg123 . CDS
                          7000
                                7600
ctg123 . CDS
                          3301
                                               ID=cds00003;Parent=mRNA00003;Name=edenprotein.3
                                               ID=cds00003; Parent=mRNA00003; Name=edenprotein.3
ctg123 . CDS
                          5000
                                5500
ctg123 . CDS
                         7000
                                7600
                                               ID=cds00003;Parent=mRNA00003;Name=edenprotein.3
ctg123 . CDS
                          3391
                                               ID=cds00004;Parent=mRNA00003;Name=edenprotein.4
                                3902
                                               ID=cds00004; Parent=mRNA00003; Name=edenprotein.4
ctg123 . CDS
                          5000
                                     . + 1 ID=cds00004;Parent=mRNA00003;Name=edenprotein.4
ctg123 . CDS
                          7000
```

#### **Columns:**

Seqname

Source

**Feature** 

Start

End

Score

Strand

Frame

**Attribute** 

GFF is derived from GTF

https://m.ensembl.org/info/website/upload/gff.html

## SAM (Sequence Alignment Format)

- Read mapping will output a SAM file, which is a sequence file that includes alignment information
- SAM files are then analyzed with another program to determine read counts per gene (obviously a GFF file would have to be involved, too)
- BAM files are a binary form of SAM files (essentially compressed to speed up operations)
- SAM/BAM files contain a lot of information, so they are not very intuitive

```
@HD
      VN:1.0 SO:coordinate
@S0
      SN:chr20
                   LN:64444167
@PG
      ID:TopHat
                   VN:2.0.14
                               CL:/srv/dna tools/tophat/tophat -N 3 --read-edit-dist 5 --read-rea
lign-edit-dist 2 -i 50 -I 5000 --max-coverage-intron 5000 -M -o out /data/user446/mapping tophat/index/chr
20 /data/user446/mapping tophat/L6 18 GTGAAA L007 R1 001.fastq
HWI-ST1145:74:C101DACXX:7:1102:4284:73714
                                      16
                                                   190930 3
                                            chr20
                                                                100M
     {\sf CCGTGTTTAAAGGTGGATGCGGTCACCTTCCCAGCTAGGCTTAGGGGATTCTTAGTTGGCCTAGGAAATCCAGCTAGTCCTGTCTCTCAGTCCCCCCTCT}
   AS: i:-15
               XM:i:3 X0:i:0 XG:i:0 MD:Z:55C20C13A9 NM:i:3 NH:i:2 CC:Z:= CP:i:55352714
                                      16
                                            chr20
                                                   193953 50
HWI-ST1145:74:C101DACXX:7:1114:2759:41961
                                                                100M
     TGCTGGATCATCTGGTTAGTGGCTTCTGACTCAGAGGACCTTCGTCCCCTGGGGCAGTGGACCTTCCAGTGATTCCCCTGACATAAGGGGCATGGACGA
   AS: i:-16
               XM:i:3 X0:i:0 XG:i:0 MD:Z:60G16T18T3 NM:i:3 NH:i:1
HWI-ST1145:74:C101DACXX:7:1204:14760:4030
                                                   270877 50
                                      16
                                            chr20
                                                                100M
     DDDDDDDDDDDDDDDDDDDDDDEEEEEEFFFEFFEGHHHHFGDJJIHJJIJJJIIIIIGGFJJIHIIIJJJJJJIGHHFAHGFHJHFGGHFFFDD@BB
   AS:i:-11
               XM:i:2 X0:i:0 XG:i:0 MD:Z:0A85G13
                                                NM:i:2 NH:i:1
HWI-ST1145:74:C101DACXX:7:1210:11167:8699
                                            chr20
                                                   271218 50
                                                                50M4700N50M
            GTGGCTCTTCCACAGGAATGTTGAGGATGACATCCATGTCTGGGGTGCACTTGGGTCTCCGAAGCAGAACATCCTCAAATATGACCTCTCG
accepted hits.sam
```

Here is a detailed account of SAM format: <a href="https://samtools.github.io/hts-specs/SAMv1.pdf">https://samtools.github.io/hts-specs/SAMv1.pdf</a>
In general, the casual user doesn't need to look inside a sam file. Tools such as samtools can be used to manipulate them.

### Running Jobs in the Background

https://linuxize.com/post/how-to-use-linux-screen/

- Use the utility "screen"
  - Just type **screen** to create a new screen session
  - Run your script/command in this new session
  - Press Ctrl-a and then d to detach from the session
  - Type **screen** -r to reattach to the session
  - After you detach, you can log off and your script will keep running
  - Press Ctrl-a and then \ to terminate all screen sessions
  - See the link above for more details.

### By Thursday:

 Download your sequence read file from the SRA and transfer it to the server (this will take a while)

 Bernadette has already downloaded your genome and gff file, which will be necessary for the read mapping